



CAUTION! Do not use 1-2 jumper position on JB1 unless U3 is installed!

3.3 Volt VCC

SECONDARY I/O AND MEMORY EXPANSION

OPTIONAL

JB2 Settings:
 =====
 RS485: jumper 2-4 and 1-3
 RS232: jumper 6-4 and 5-3
 neither: all jumpers off

JB3 Settings:
 =====
 Single Chip Mode: jumper 2-4 and 1-3
 Refer to 9S12NE64 device guide for details of other modes

www.technologicalarts.com
 support@technologicalarts.com sales@technologicalarts.com

TECHNOLOGICAL ARTS, INC.

Title: **Adapt9S12NE64**

Size C Document Number FILE: AD9S12NE64R1.DSN Rev 1a

Date: Saturday, January 16, 2010 Sheet 1 of 1

Rev. 1a: fixed U1 pins 85..92 signal names

for Serial Monitor